Note! Before using the Drester 1050, it is importan that you have read and fully understand the User´s Manual.

CLEANING:

For best cleaning result, spray guns should be cleaned immediately after use.

* Disconnect the spray gun from compressed air and empty any remaining paint into a paint waist container. To start the pump and activate the flow of cleaning fluid, press the foot pedal (#10).

* Clean the cup and the cap using the rinse gun (#2) and the brush (#1).

* Clean the paint channel of the spray gun using the rinse gun (#2).

* Clean the outside of the spray gun using the rinse gun (#2) and the brush (#1).

* Dry the spray gun, cup and cap using the blow gun (#5).

* In addition to the steps above, you can connect the blow-out air line (#11) to your spray gun to blow out any remaining fluid.

FLOCCULATION AND FILTRATION:

When the mix of paint and water reaches the level of the working platform (#4) it is time to perform the flocculation and filtration.
It is important that the flocculation is thouroughly carried out. If not, the filters (#7 and #8) will become obstructed and cannot be re-used.

* Make sure the filtrate container (#9) is empty. (Maximum one inch of fluid left in the container)

* Remove the working platform (#4).

* Turn the lever (#3) to start the agitation.

* While stirring with a measuring stick or similar, add flocculation powder, as recomended by the paint manufacturer, usually approximately five scoops for full batch using Drester 9211 flocculation powder.

* When all flocculation powder is thouroughly mixed in, let the agitation run for three minutes. Let it rest for one minute. Turn the agitator on for one more minute.

* Remove any sludge from the pre-filter (#7) and open the drain valve (#6) to drain the dirty water through the filters.

* Clean the inside of the sink and close the drain valve (#6). Re-fit the working platform (#4).